

PressurePro Lock Nut Kit Installation Instructions

The lock nut kit is provided for use by PressurePro users for locking PressurePro Sensors onto the valve stem. The lock nuts can be used on all types of vehicles with valve stems (with the exception of large bore valves).

Installation Instructions

1. Remove cap, or Sensor, from valve stem
2. Screw lock nut onto stem (all the way down)
3. Screw sensor onto valve stem (hand tighten, firmly)
4. Use wrench tool to tighten the nut firmly to the bottom of the Sensor

Note: PressurePro suggests storing the Lock Nut wrench in a safe place for storage.